



**MAINTENANCE TIPS FOR PUTTING YOUR
EQUIPMENT INTO STORAGE**

Maintenance Tips for Putting Your Equipment in Storage

1. Drain and change the oil and service the air filter. Check the service manual for other recommendations.
2. Inspect for broken parts, and replace any that are broken or damaged
3. Remove the battery and full charge before storing.
4. Add fuel stabilizer to the gas tank, then run the equipment to distribute it. Turn the engine off, allow the machine to cool, then restart and run until the gas tank is empty.
5. Store in a clean and dry place, sheltered from the winter weather.

